

TIMEX INSTRUCTIONS

SPECIAL EXTENDED WARRANTY OFFER

SPECIAL EXTENDED WARRANTY OFFER

5 YEARS FOR 5 DOLLARS

For \$5, Timex will extend the enclosed one year limited manufacturer's warranty for an additional 4 years from date of purchase. This 5 year warranty covers repairs on your watch under the same terms and conditions as set forth in the manufacturer's warranty in this booklet.

Payment can be made with AMEX, Discover, Visa or MasterCard by calling 1-800-448-4639 during normal working hours or you can mail a check to:

Timex Extended Warranty
P.O. Box 1676, Dept. EF
Little Rock, AR 72203.

We will need your name, address, telephone number, date watch purchased and 5 digit watch model number.

Payment must be made within 30 days after date of purchase.

Please read this booklet carefully to familiarize yourself with the operation of your Timex stopwatch with the Limited Warranty.

SECTION 1 – INDIGLO® NIGHT-LIGHT

Your Timex stopwatch featuring INDIGLO night-light contains a patented electroluminescent technology (U.S. Patent Number 4,527,096). The INDIGLO night-light illuminates the entire stopwatch lens with a uniform bright light that offers superior readability in all low light and nighttime conditions. Simply press the INDIGLO night-light button to activate.

INDIGLO is a registered trademark of Indiglo Corporation in the U.S. and other countries.

SECTION 2 – WATER-RESISTANCE

If your stopwatch is water-resistant, it will be indicated (☞) on the face or on the caseback.

- **50 Meter Water-Resistant** stopwatch withstands water pressure to 86 p.s.i.a. (equals immersion to 164 feet or 50 meters below sea level).

WARNING:

TO MAINTAIN WATER-RESISTANCE, DO NOT PRESS ANY BUTTONS UNDER WATER UNLESS YOUR STOPWATCH IS INDICATED AS 200 METER WATER-RESISTANT.

NOTES:

1. The stopwatch is water-resistant only as long as lens, push buttons and case remain intact.
2. Even though the stopwatch may be water-resistant to a significant depth (100 or 200 meters), it should not be used for diving.
3. Timex strongly recommends rinsing your stopwatch with fresh water after exposure to salt water.

SECTION 3 – PRODUCT INTRODUCTION

First acquaint yourself with the four buttons that operate the stopwatch.

LAP•SPLIT/RESET

START/STOP



INDIGLO
 night-light

Mode
 Indicators

MODE

FEATURES

- 10 hour working range, accurate to 1/100th second. If timing exceeds 10 hours, timing restarts from **0:00.00.00**.
- First and second place finishes.
- Unlimited lap and split times.
- Stopwatch beeps every time a button is pressed (except INDIGLO and MODE).
- Mode selection even while the stopwatch is in operation.



SECTION 4 – HOW TO OPERATE STOPWATCH

NOTES:

1. NET or TOTAL ACCUMULATED TIME can be measured in either mode.
2. LAP mode allows you to measure consecutive segments of an event (laps).
3. SPLIT mode allows you to capture the elapsed time at any point during an event while chronograph continues to operate and to measure first and second place finishes.
4. Select between LAP or SPLIT functions by pressing **MODE**.

STOPWATCH OPERATIONS

From the reset stopwatch **0:00.00.00**, press **MODE** to select LAP or SPLIT timing (bar flashing underneath "LAP" or "SPLIT").



NET OR TOTAL ACCUMULATED TIME

1. Press **START/STOP** to start stopwatch operation.
2. Press **START/STOP** to stop stopwatch operation (a bar under the "STOP" indicator will appear below 1/100 seconds).
3. Press **START/STOP** to start stopwatch again.

OR

4. Press **LAP•SPLIT/RESET** to clear stopwatch. You are now ready to start again.

LAP TIMING

1. From LAP mode, press **START/STOP** to start stopwatch.
2. Press **LAP•SPLIT/RESET** to record time of first lap. Stopwatch simultaneously begins operation from **0:00.00.00** to record the next lap time.
3. Press **LAP•SPLIT/RESET** to view elapsed time of next lap.
4. Press **LAP•SPLIT/RESET** to record next lap, etc. (You may continue this indefinitely.)

OR

5. Press **START/STOP** to pause the stopwatch, or to end the timing session and record final lap.
6. Press **LAP•SPLIT/RESET** to clear stopwatch. You are now ready to start again.

SPLIT TIMING

1. From SPLIT mode press **START/STOP** to start stopwatch.
2. Press **LAP•SPLIT/RESET** to record split time (digits stop advancing, but stopwatch continues to run).
3. Press **LAP•SPLIT/RESET** to release split time (stopwatch begins running again). Display will now show total elapsed running time.
4. Press **LAP•SPLIT/RESET** to record next split time (you may continue this indefinitely).

OR

5. Press **START/STOP** to pause the stopwatch, or to end the timing session.
6. Press **LAP•SPLIT/RESET** to clear stopwatch. You are now ready to start again.

FIRST AND SECOND PLACE FINISH

1. From SPLIT mode press **START/STOP** to start stopwatch.
2. Press **LAP•SPLIT/RESET** to record first place finish.
3. Press **START/STOP** to record (but not view) second place finish and stop stopwatch.
4. Press **LAP•SPLIT/RESET** to view second place finish.
5. Press **LAP•SPLIT/RESET** to clear stopwatch. You are now ready to start again.

SECTION 5 – BATTERY REPLACEMENT

One battery provides the power to operate your Timex stopwatch. **TIMEX STRONGLY RECOMMENDS TAKING YOUR WATCH TO A LOCAL RETAILER OR JEWELER TO HAVE THE BATTERY REPLACED.** The battery type required for your stopwatch is indicated on the caseback.

CAUTION: DO NOT DISPOSE OF OLD BATTERY IN FIRE OR ATTEMPT TO RECHARGE. KEEP LOOSE BATTERIES AWAY FROM CHILDREN.

When installed at the factory, the battery life in this Timex stopwatch is estimated to last 4 years or as specified on the package. This estimate is based on the light being used once per day for one second. Battery life may vary depending on your actual usage experience.

SECTION 6 – SERVICE

If your TIMEX stopwatch should ever need servicing, send it to Timex addressed as follows:

**HOTLINE WATCH SERVICE
P.O. Box 2740
Little Rock, AR 72203**

For service questions, call 1-800-448-4639.

For your convenience in obtaining factory service, participating Timex Retailers can provide you with a pre-addressed Watch Repair Mailer.

See the Limited Warranty for specific instructions on the care and service of your Timex stopwatch.

LIMITED WARRANTY

The Basic Coverage: This TIMEX Quartz Digital L.C.D. (liquid crystal display) stopwatch (but not any battery or lens) is warranted to the owner for a period of **ONE YEAR** from the date of purchase against defects in manufacture by Timex Corporation - not by the dealer from whom the stopwatch was purchased.

What Timex Will Do: If this stopwatch develops such a defect within the one year period, it will be repaired (i.e., a new or thoroughly reconditioned and inspected module will be installed) or replaced (a stopwatch of equal value and similar appearance will be supplied) at our option, provided it is returned with a \$5.00 check or money order to cover costs of postage, handling and service, and you provide proof of purchase and date of purchase.

This Limited Warranty Does Not Cover:

- 1) Timex will not repair defects related to servicing not performed by Timex Corporation.
- 2) Timex will not provide any warranty service if your stopwatch shows evidence that it has been tampered with, misused, abused, or altered; for example:
 - moisture damage sufficient to affect the proper function of the stopwatch;
 - damage to the case; or
 - visible cracking of the lens.
- 3) Timex reserves the right to charge you for a replacement battery, if the battery in your stopwatch is depleted. No additional charge will be made unless the one year warranty period has expired or servicing is necessary for reasons beyond our control, in which case a moderate charge will be made.
- 4) TIMEX IS NOT LIABLE FOR INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES. Some states do not allow the exclusion or limitation of incidental, special or consequential damages, so the above exclusion or limitation may not apply to you.

Your Rights Under Implied Warranties and State Law: THIS LIMITED WARRANTY IS IN LIEU OF ALL OTHER EXPRESSED WARRANTIES, OBLIGATIONS OR LIABILITIES. TIMEX LIMITS THE DURATION OF ANY WARRANTY IMPLIED BY STATE LAW, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, TO ONE YEAR FROM THE DATE OF ORIGINAL PURCHASE. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Care of Your Stopwatch:

- Avoid exposing your stopwatch to water, steam, or other forms of moisture if it is non-water-resistant.
- If the lens becomes damaged, have it replaced at once to avoid damage to the module.
- When your battery is depleted, have it replaced promptly. The particular type of battery required is indicated on the back. You can get them from your local Timex retailer.

Service of Your Stopwatch:

If your TIMEX stopwatch should ever need servicing, send it to Timex addressed as follows: **HOTLINE WATCH SERVICE, P.O. Box 2740, Little Rock, AR 72203**

Because of possible loss, we recommend insuring your stopwatch, return receipt requested, when using the mails. If you do not obtain a receipt within a reasonable time, start a tracer through the originating post office. **NEVER INCLUDE ANY ARTICLE OF PERSONAL VALUE IN YOUR SHIPMENT. PLEASE NOTE THAT WE MAY SUBSTITUTE A STOPWATCH OF EQUAL VALUE AND SIMILAR APPEARANCE FOR YOURS ON BOTH IN-WARRANTY AND OUT-OF-WARRANTY REPAIRS.**

For your convenience in obtaining factory service, participating Timex retailers will be pleased to provide you with a postage-paid, pre-addressed Watch Repair Mailer.

TIMEX is a trademark and a service mark of Timex Corporation.

REG. U.S. PAT. & TM. OFF.